

Exclusive Distributor for India

Introducing the new
PX-20 & PX-30

MOISTURE METERS FOR PAPER



MOISTURE METERS

The next generation of moisture meters is here, with the introduction of the **Navigator™** series and **EDGE™** app from Delmhorst.

NEW PX-20 AND PX 30

The **PX-20 and PX-30** are the latest in the new Navigator™ family of moisture meters from Delmhorst. Uniquely designed for use in the field, the PX-20 and PX-30 feature a dashboard-like display that is easy to read under most conditions, and large, easy to use navigation buttons.

With the **PX-20 and PX-30 Digital Paper Meters**, the contact pins mounted on the top of the meter are used for making direct contact with the material. Various external electrodes are also available for specific applications. The PX-20 and PX-30 are especially useful for testing paperboard, corrugated stock, and paper cores and tubes. They are ideal for QC personnel, buyers, and salespeople.

The **PX-30** includes Bluetooth®, enabling connection to the Delmhorst **EDGE™** app with customizable settings and the ability to share the data from anywhere.



Product Features

- Large, custom display with auto backlight – easy to read under all conditions
- Modern case design with large, tactile buttons and E-Z grip handle
- On-screen statistics for up to 100 readings saved to the meter - High, Low, Average, Standard Deviation Moisture Range:
 - 4.3%-18% MC for paper (kraft paper calibration)
 - 5%-40% for baled scrap paper
- 0 - 100 reference scale for obtaining relative moisture levels on other materials without calibration
- Temperature correction (°F / °C - PX-30 baled and scrap only)
- Bluetooth® connectivity (PX-30)
- Color-coded LEDs – adjustable through **EDGE™** app (PX-30)
- Alarm set point - alerts to user-selected MC level
- Internal calibration check
- “Low Batt” warning with audio
- Auto off timer. Set to 1m, 4m or 10m
- Compatible with existing Delmhorst prods and electrodes

Meter Specifications:

- Power: 2x AA Alkaline batter Op Temp: 0-255° F (-18-124°C)
- QR code on meter for easy access to support materials and meter registration
- Size: meter only - 8.65in x 2.85in x 1.60in (21.97cm x 7.24cm x 4.06cm)
- Weight: meter only - 8.6oz (244gm)
- Hard plastic carrying case included
- 2-year warranty on manufacturer’s defects. Bonus warranty with on-line registration

The Delmhorst **EDGE™** app offers:

- Timestamp and geotag
- Data export to .csv format
- Save unlimited readings
- Customized LED ranges

Electrodes and prods are interchangeable. Others are available to accommodate most applications.

*Manufactured by Delmhorst in the United States of America

Exclusive Distributor for India

Quality Control Testing Instruments For

Paint & Powder Coating | Corrosion & Weathering Tester | Colour Spectro | Adhesive | Chemical
Cosmetic | Textile | Packaging | Oil & Petroleum | Paper, Printing Ink | Pharma & Food | Plastic

Certification

ISO 9001 : 2015 CERTIFIED

CRISIL SME 1* CERTIFIED

